



NOTE: ALL THE SIGNALS FROM THE PIC16F1847 WITH THE EXCEPTION OF RA1-RA4 PASS-THRU TO THE 1088XLD
 THE TK-II (V2.5J) FIRMWARE IS SPECIAL FOR THIS APPLICATION, AND CANNOT BE USED WITHOUT THIS PCB
 ARROW KEYS EQUATE TO A JOYSTICK DIRECTION (NO DIAGONALS), AND THE LEFT-WIN KEY BECOMES THE TRIGGER
 ALL OUTPUTS ARE MOMENTARY IN NATURE, ONLY REMAINING ON SO LONG AS THE ACTIVATING KEY IS PRESSED

An AtariBits Project

ARROW2JOY-XLD

MYTEK

Rev 1.0
 1/13/2020

Page 1 of 1